

Installation Instructions

1. First, make sure the perimeter seals are installed based on their separate instruction sheet.
2. Seals and brackets installed at the head will require the closer body to be installed lower on the door.
3. Place the mounting bracket over the seal where the exit device strike or door closer shoe is to be mounted.
4. Mark the screw holes accordingly.
5. Drill the pilot holes for screws using an 11/64" drill bit.
6. Secure the bracket with the included screws (#12 x 1-1/4").
7. Install exit device strike or closer shoe onto the mounting bracket according to their separate instructions.

