

## Installation Instructions

1. Cut astragal to length as required.
2. Place astragal as shown above, with brush pile slightly compressed.
3. Mark screw holes. Drill holes for screw with #31 or 3mm drill bit.
4. Install the astragal with screws provided, working from top down.
5. Adjust astragal so it does not impede proper closing and latching of doors.

