



LEGACY
MANUFACTURING



EMAIL

contact@legacyllc.com



PHONE

Local: +1 (718) 292-5333

Toll Free: +1 (888) 383-3330



WEBSITE

LegacyLLC.com



ADDRESS

415 Concord Avenue,
Bronx, NY 10455

Installation Instructions

DOOR SWEEPS

Surface Mounted Mortisted Door Sweeps Rain Drips

- 1.** Measure door sill and cut the sweep to fit.
- 2.** Close door. Hold sweep making gentle contact with the threshold.
- 3.** Mark screw holes. Drill holes using #31 or 3.048mm drill bit.
- 4.** Adjust sweep position to make proper contact with the threshold, allowing smooth operation of the door.

