LegacyLLC.com

415 Concord Avenue Bronx, NY 10455 contact@legacyllc.com

Adjustable Architectural Seals **5077, 5071**

Installation Instructions

- 1. Close the door and measure the frame opening.
- **2.** Install the gasketing (trim as necessary), head piece first. Place the piece against the face of door, making gentle contact between the rubber extrusion seal and the door. Fasten in place.
- **3.** Place hinge side piece against the face of door, making gentle contact between the rubber extrusion seal and the door. Fasten in place. Repeat the same procedure with the lock side.
- **4.** It is recommended that this gasketing product be set in a bead of caulking to ensure the integrity of the seal and prevent additional sound transmission.
- **5.** Adjust #5077 (or #5071) with the adjusment screws as necessary for the desired seal and operation of the door.





