

# How To Order: Flood Barriers

#### Example #5027MA30-60



Email Orders@LegacyLLC.com **Phone** Local: +1 (718) 292-5333 Toll Free: +1 (888) 383-3330


**Fax** 33 +1 (888) 383-3330





# Single Flood Barrier for Standard Openings (Up to 48")


#### **#5027** MOUNTED TO INSIDE OF FRAME





#5027MA mounted to the inside of the door frame.

#### **#5127** MOUNTED TO OUTSIDE OF FRAME





#5127MA mounted to the outside of the door frame.



SIDE VIEW


Barriers

WWW.LEGACYLLC.COM



# Single Flood Barrier for Windows, Louvers and Fireplaces (Up to 48")


## #5028 🏵 MOUNTED TO INSIDE OF FRAME





#5128MA mounted to a basement window.

### #5128 🏵 MOUNTED TO OUTSIDE OF FRAME






#5128MA mounted to a fireplace.







SIDE VIEW



**#2275** INTERLOCKING POST WITH GROUND SUPPORT


#2275

Channels are cut to fit into the


outer sleeve below.

## Interlocking Flood Barrier for Oversized Openings (Greater than 48")

**#5029** ( MOUNTED TO INSIDE OF FRAME




#### **#5129** ( MOUNTED TO OUTSIDE OF FRAME



Recommended for every 48" of specified installed width:

Custom

Height"



Custom Width"





#5029MA mounted to the inside of garage door frame.

#5129MA mounted to front of hotel entrance.

+1 (718) 292-5333 | TOLL FREE: +1 (888) 383-3330

#5129MA36-96


33

**PRODUCT CATALOG #20** 



# **Flood Barrier Enclosures**

## **#5060** FREE STANDING




Recommended for every 48" of specified installed width:

• #2275 Interlocking Post with

#22070-0S Outer Sleeve


### **#5021** STACKABLE FLOOD BARRIER

#### **#5040** SURFACE-MOUNTED



Recommended for every 48" of specified installed width:

- #2275 Interlocking Post with
- #22070-0S Outer Sleeve



Call us to discuss your best configuration for your specific installation.